

BA 017E/FM42i/10.25

Valid starting from  
Hardware V 2.1  
Software V 129

# Flowmax<sup>®</sup> 42i

## Ultrasonic flow metering / dosing device


### Operating manual



## General safety instructions

Please always observe the following safety instructions!

Please pay attention to the safety instructions with the following pictograms and signal words in these operating instructions:



**IMPORTANT!**

**IMPORTANT!** indicates situations or cases which, if not avoided, could result in damage or failure of the Flowmax 42i equipment.



**WARNING!**

**WARNING!** indicates general hazardous situations or cases which, if not avoided, could result in serious injury or death.

**NOTICE!**

**NOTICE!** is used to lead users to helpful information not related to personal injury.

### Intended use

- The flowmeter Flowmax 42i may only be used for measuring the flow of pure, homogeneous liquids.
- The Flowmax 42i is not intended for use in medical applications.
- The volume flowmeter Flowmax 42i is built operationally safe in accordance with the latest state of the art technologized developments and industry standard EN 61010 regulations (corresponds to VDE 0411 "Safety specifications for electrical measurement, control and laboratory devices").
- The manufacturer is not liable for any injury, damage or harm due to inappropriate or unintended use or modifications of the flowmeter. Conversions and/or changes to the flowmeter may only be made, if they are expressly performed in accordance with the operating instructions in this operating manual.

### Personnel for installation, commissioning and operation

- **Assembly, electrical installation, commissioning and maintenance of the flowmeter must be carried out by qualified, trained personnel. The qualified personnel must have read and understood the operating instructions in this operating manual and must follow the operating instructions in this manual.**
- **The installer has to ensure that the flowmeter is correctly connected according to the electrical connection diagrams in this operating manual.**
- **Serious injury or death from electric shock may occur if wiring, installation, disassembly or remove of wires is performed while electrical power is energized**



**WARNING!**

### Technological progress

The manufacturer reserves the right to revise, alter, or modify the flowmeter to the most current technology without special prior notice. Further information about the latest updates and potential additions to these operating instructions are available from the manufacturer.

## Table of contents

<b>General safety instructions</b> .....	<b>2</b>
<b>Table of contents</b> .....	<b>3</b>
<b>Table of figures</b> .....	<b>4</b>
<b>1. Planning information</b> .....	<b>5</b>
1.1 Areas of application.....	5
1.2 Measuring principle.....	5
1.3 Operational safety.....	6
<b>2. Assembly and installation</b> .....	<b>7</b>
2.1 Installation instructions.....	7
2.2 Assembly of the flowmeter.....	8
2.3 Electrical wiring.....	10
<b>3. Commissioning</b> .....	<b>16</b>
3.1 Operation.....	16
3.1.1 Display and user menu.....	17
3.2 Functionalities of flowmeter and default settings.....	20
3.2.1 Language.....	20
3.2.2 Dosing.....	20
3.2.3 Media.....	21
3.2.3.1 Set Offset.....	21
3.2.3.2 1-Pt-Correction.....	21
3.2.3.3 Creeping suppression.....	21
3.2.3.4 Basic Trim.....	22
3.2.4 General Settings.....	23
3.2.4.1 Reset Counter.....	23
3.2.4.2 TPG (tolerance against solid particles and gas inclusions) (option).....	23
3.2.4.3 Empty pipe delay.....	23
3.2.4.4 Hysteresis.....	24
3.2.4.5 Lower Limit.....	24
3.2.4.6 Upper Limit.....	24
3.2.4.7 Pulse value.....	25
3.2.4.8 Total Counter.....	25
3.2.4.9 Counter.....	25
3.2.5 Display.....	26
3.2.5.1 Units.....	26
3.2.5.2 Filter for Display.....	26
3.2.5.3 Rotate Display.....	26
3.2.5.4 Flashing.....	27
3.2.6 Analog Output QA.....	27
3.2.6.1 Function.....	27
3.2.6.2 Filter.....	29
3.2.6.3 Output Value.....	29

3.2.7 Digital Outputs Q1 and Q2 (Q2 only available with 8-pin plug) .....	31
3.2.8 Digital Input I1 (only available with 8-pin plug) .....	33
3.2.9 Diagnostic .....	33
3.2.9.1 Testing Flow .....	33
3.3 Overview of default settings .....	34
3.4 General Information .....	34
<b>4. Exchange of flowmeter .....</b>	<b>35</b>
<b>5. Technical specifications .....</b>	<b>36</b>
5.1 Dimensions and weight of the compact version .....	36
5.2 Dimensions and weight of the separated version .....	37
5.3 Technical specifications .....	38
<b>6. Accessories .....</b>	<b>39</b>
<b>7. Shipment .....</b>	<b>39</b>
<b>Appendix .....</b>	<b>40</b>

## Table of figures

Figure 1: Presentation of the principle of ultrasonic flow measuring .....	5
Figure 2: ideal installation position of Flowmax 42i in the compact version .....	7
Figure 3: ideal installation position of Flowmax 42i in the separated version .....	7
Figure 4: Mounting examples for Flowmax 42i .....	8
Figure 5: Mounting possibilities .....	9
Figure 6: Fixing Flowmax 42i .....	9
Figure 7: Flowmax 42i mounted on a DIN rail .....	9
Figure 8: Pin code: Connection plug / socket for 5-pin version .....	10
Figure 9: Pin code: Connection plug / socket for 8-pin version .....	12
Figure 10: Pin code: Connection plug / socket for 8-pin version .....	13
Figure 11: Operating with the key pad .....	17
Figure 12: Menu structure Flowmax 42i .....	19
Figure 13: Function of creeping suppression illustrated with 0.6 l/min .....	21
Figure 14: Function Lag Creeping Flow .....	22
Figure 15: Function Hysteresis at limit .....	24
Figure 16: The analog output is active .....	27
Figure 17: Characteristic curve 0 ... 20mA .....	28
Figure 18: Characteristic curve 4 ... 20mA .....	28
Figure 19: Function Filter of analog output .....	29
Figure 20: Deviation of temperature measurement .....	30
Figure 21: Connecting Digital Output to relay .....	32
Figure 22: Connecting Digital Output to counter .....	32

## 1. Planning information

### 1.1 Areas of application

The flow measurement device Flowmax 42i is designed to measure dynamic flow in pipes and tubes. This flowmeter is suitable for liquids only. The Flowmax 42i is used in

- Chemicals supply for controlling, logistics, monitoring
- Cooling systems, logistics, monitoring
- Process equipment for control and monitoring of formulas
- Valve control for continuous release of liquid volumes
- Supply with de-ionized water
- Very dynamic liquid processes with dosing times of below 1 second

Flowmax 42i has the following features and benefits:

- No movable parts, therefore no wear
- High repeatability
- Easy to clean
- Safe operation
- Compact design
- Integrated detection of empty conduits
- Integrated dosing function with pre-set and adjustable amounts
- Chemical resistant
- Constant pipe cross-section over the entire measurement channel

### 1.2 Measuring principle

It usually takes more energy to swim against the flow than with the flow. The ultrasonic flow measurement is based on the phase-difference approach:

Two ultrasonic-sensors located opposite from each other alternatively transmitting and receiving ultrasonic signals. If there is no liquid flow both sensors receive the transmitted ultrasonic signals in the same phase, i.e. without phase difference. If liquid is flowing there is a phase shift. It differs when measured in direction of the flow than when measured against the direction of the flow. This phase difference is directly proportional to the flow rate.




Figure 1: Presentation of the principle of ultrasonic flow measuring

### 1.3 Operational safety

Comprehensive self-tests ensure highest possible safety.  
Faults (process or system errors) are output on a digital output or displayed on the display menu.

The protection class is IP 65.

Flowmax 42i meets the general EMC immunity requirements according to CE, EN 61000-6-3, EN 61000-4-2, EN 61000-4-3, EN 61000-4-4, EN 61000-4-5, EN 61000-4-6.

Flowmax 42i meets the safety requirements concerning the Protective Extra Low Voltage directive according to EN 50178, SELV, PELV.

## 2. Assembly and installation

### 2.1 Installation instructions

The arrow on the nameplate of the Flowmax 42i shows the positive flow direction. The flowmeter has to be installed in a way so that the flow-through is in the same direction as the arrow symbol.

**NOTICE!**




Figure 2: ideal installation position of Flowmax 42i in the compact version




Figure 3: ideal installation position of Flowmax 42i in the separated version

For fastest possible bubble detection it is important to keep the pipe distance from tank to Flowmax 42i as short as possible. Accurate measurement can only be assured, if the pipe is completely filled and the liquid does not outgas.

Notwithstanding it may be advantageous for dosing applications to install the Flowmax 42i as close as possible to the dosing valve, as soft pipes change the cross-section depending on the system pressure. This may lead to repeatable differences.

Insure that no cavitation dissolve from the measured liquid. Depending on the measured liquid it can be helpful to have enough back pressure on the outlet of Flowmax 42i to avoid cavitation. Insure all mechanical connections are tight.

**NOTICE!**

Particles present in the flow stream may result in measuring errors.

When using pumps, Flowmax 42i must be installed in flow direction on the pressure side, in order to ensure sufficient pressure. The maximum pressure rating of Flowmax 42i has to be considered.

**WARNING!**

**Do not exceed the maximum pressure allowance for of the Flowmax 42i (see section 5.3 Technical specifications). Exceed the maximum pressure can lead to destruction of the Flowmax 42i.**



For correct volume flow measurements straight and unobstructed inflow and outflow distances have to be observed. Starting from the connection thread these straight and unobstructed flow zones must be:

Nominal diameter	DN 3	DN 5	DN 7	DN10	DN15
Inflow distance	0cm	0cm	0cm	5cm	40cm
Outflow distance	0cm	0cm	0cm	0cm	20cm

**2.2 Assembly of the flowmeter**

The flowmeter is mounted into a pipe system by using the mechanical connection. Flowmax 42i should be mounted vertically into the pipe for the best measuring performance. Do not install the flowmeter after a dosing valve where the flowmeter can run empty. Placing the flowmeter after a dosing valve and allowing it to run empty will cause a measuring deviation at the next measurement. To avoid bubbles in the liquid, Flowmax 42i should be installed on the pressure side of the pump.



It is recommended to place the pump in the same plane as the container. Thus, the pump runs independently full and there is caused no vacuum when promoting.




Figure 4: Mounting examples for Flowmax 42i

If it is not possible to mount the flowmeter vertically, then mount the flowmeter in a location where the pipe will be filled at all times. The best measuring result is achieved if bubbles do not pass through Flowmax 42i.

**IMPORTANT!**

Flowmax 42i must be installed without mechanical tensions on the existing pipe system. The flowmeter may be damaged if there is tension on the existing pipe system.

**WARNING!**

**Non-compliance of the installation instructions may result in tearing of the housing, liquid may leak out.**



**IMPORTANT!**



**WARNING!**




Figure 5: Mounting possibilities

For applications with a “clean design“ for which it is necessary to completely drain the pipe system, we recommend mounting the flowmeter in the vertical position. Residual liquid may remain inside the device if flowmeter is mounted horizontally.

Vibrations or mechanical forces may decrease measuring accuracy. So if there is due to vibration or mechanical movements is necessary to fix Flowmax 42i additionally, the instrument can be either mounted on a DIN rail, or be fixed on the lateral slot.




Figure 6: Fixing Flowmax 42i




Figure 7: Flowmax 42i mounted on a DIN rail

### 2.3 Electrical wiring

**Do not install, wire or dismantle the measuring device while it is under operating voltage. The supply voltage to the Flowmax 42i must be switched off during these procedures.**



Figure 8: Pin code: Connection plug / socket for 5-pin version

Connector cable pin configuration defined by manufacturer.

The outlets may be re-programmed for specific applications.

#### 5-pin plug with 1-wire communication:

Pin	Function	Description
1	24 VDC	Power supply: 18 ... 30 VDC
2	Digital Output Q1	Freely adjustable in the range from 0.1 to 3000 ml/pulse (or ml/s/Hz), in steps of 0.1. NPN or PNP transistor. Maximum load 100mA. Max. Voltage must be less than supply voltage.
	1. Pulse Output	Output in ml/pulse, depending on the pulse value setting.
	2. Increased tolerance for particle or gas inclusions (TPG)	Programmable output of 0V or 24V on detection of solid particles or air bubbles and change to "TPG" software mode.
	3. Frequency output	Output in Hz, depending on the pulse value setting.
	4. Dosing	Programmable output of 0V or 24V while dosing is running.
	5. Negative Flow	Programmable output of 0V or 24V in case of negative flow.
	6. Lower or upper limit (limit value monitoring)	Programmable output of 0V or 24V when an adjustable limit is undercut/exceeded.
7	Empty Pipe	Programmable output of 0V or 24V when the measuring pipe is empty or too many bubbles/particles detected.
3	GND	Power supply ground: 0 V
4	Communication	Communication interface
5	Analog Output QA	4 ... 20mA; 0 ... 20mA
		For example: 0l/min → 4mA 36l/min → 20mA (depending on the nominal diameter) Empty pipe alarm → 3,5mA

**5-pin plug with RS485 communication and analog output:**

Pin	Function	Description
1	24 VDC	Power Supply: 18 ... 30 VDC
2	Communication	RS485B
3	GND	Power supply ground: 0 V
4	Communication	RS485A
5	Analog Output QA	4 ... 20mA; 0 ... 20mA
		For example: 0l/min → 4mA 36l/min → 20mA (depending on the nominal diameter) Empty pipe alarm → 3,5mA

**5-pin plug with RS 485 – communication and digital output Q1:**

Pin	Function	Description
1	24 VDC	Power Supply: 18 ... 30 VDC
2	Digital Output Q1	Freely adjustable in the range from 0.1 to 3000 ml/pulse (or ml/s/Hz), in steps of 0.1. NPN or PNP transistor. Maximum load 100mA. Max. Voltage must be less than supply voltage.
	1. Pulse Output	Output in ml/pulse, depending on the pulse value setting.
	2. Increased tolerance for particle or gas inclusions (TPG)	Programmable output of 0V or 24V on detection of solid particles or air bubbles and change to "TPG" software mode.
	3. Frequency output	Output in Hz, depending on the pulse value setting.
	4. Dosing	Programmable output of 0V or 24V while dosing is running.
	5. Negative Flow	Programmable output of 0V or 24V in case of negative flow.
	6. Lower or upper limit (limit value monitoring)	Programmable output of 0V or 24V when an adjustable limit is undercut/exceeded.
	7. Empty Pipe	Programmable output of 0V or 24V when the measuring pipe is empty or too many bubbles/particles detected.
3	GND	Power supply ground: 0 V
4	Communication	RS485A
5	Communication	RS485B

**8-pin plug with 1-wire communication:**



Figure 9: Pin code: Connection plug / socket for 8-pin version

**8-pin plug assignment with factory-assigned outputs**

Pin	Function	Description
1	24 VDC	Power Supply: 18 ... 30 VDC
2	Digital Output Q1	Freely adjustable in the range from 0.1 to 3000 ml/pulse (or ml/s/Hz), in steps of 0.1. NPN or PNP transistor. Maximum load 100mA*. Max. Voltage must be less than supply voltage.
	1. Pulse Output	Output in ml/pulse, depending on the pulse value setting.
	2. Increased tolerance for particle or gas inclusions (TPG)	Programmable output of 0V or 24V on detection of solid particles or air bubbles and change to "TPG" software mode.
	3. Frequency output	Output in Hz, depending on the pulse value setting.
	4. Dosing	Programmable output of 0V or 24V while dosing is running.
	5. Negative Flow	Programmable output of 0V or 24V in case of negative flow.
	6. Lower or upper limit (limit value monitoring)	Programmable output of 0V or 24V when an adjustable limit is undercut/exceeded.
	7. Empty Pipe	Programmable output of 0V or 24V when the measuring pipe is empty or too many bubbles/particles detected.
3	GND	Power supply ground: 0 V
4	Digital Output Q2	Freely adjustable in the range from 0.1 to 3000 ml/pulse (or ml/s/Hz), in steps of 0.1. NPN or PNP transistor. Maximum load 100mA*. Max. Voltage must be less than supply voltage.
	1. Pulse Output	Output in ml/pulse, depending on the pulse value setting.
	2. Increased tolerance for particle or gas inclusions (TPG)	Programmable output of 0V or 24V on detection of solid particles or air bubbles and change to "TPG" software mode.
	3. Frequency output	Output in Hz, depending on the pulse value setting.
	4. Dosing	Programmable output of 0V or 24V while dosing is running.
	5. Negative Flow	Programmable output of 0V or 24V in case of negative flow.
	6. Lower or upper limit (limit value monitoring)	Programmable output of 0V or 24V when an adjustable limit is undercut/exceeded.
	7. Empty Pipe	Programmable output of 0V or 24V when the measuring pipe is empty or too many bubbles/particles detected.
5	Analog Output QA	4 ... 20mA; 0 ... 20mA
		For example: 0l/min → 4mA 36l/min → 20mA (depending on the nominal diameter) Empty pipe alarm → 3,5mA
6	Communication	Communication interface
7	Digital input I1	
	1. Dosing	Starts the dosing process at 24V edge.
	2. Set Offset	Starts offset adjustment, at 24V edge.
	3. Reset Counter	Reset the counter on 24V edge
	4. Creeping Flow Off	Deactivates the creeping flow suppression while 24V is active.
8	Shield	EMC safety

\* Q1 + Q2 ≤ 100mA

**8-pin plug with RS 485 communication:**

Figure 10: Pin code: Connection plug / socket for 8-pin version

Pin	Function	Description
1	24 VDC	Power supply: 18 ... 30 VDC
2	Digital Output Q1	Freely adjustable in the range from 0.1 to 3000 ml/pulse (or ml/s/Hz), in steps of 0.1. NPN or PNP transistor. Maximum load 100mA. Max. Voltage must be less than supply voltage.
	1. Pulse Output	Output in ml/pulse, depending on the pulse value setting.
	2. Increased tolerance for particle or gas inclusions (TPG)	Programmable output of 0V or 24V on detection of solid particles or air bubbles and change to "TPG" software mode.
	3. Frequency output	Output in Hz, depending on the pulse value setting.
	4. Dosing	Programmable output of 0V or 24V while dosing is running.
	5. Negative Flow	Programmable output of 0V or 24V in case of negative flow.
	6. Lower or upper limit (limit value monitoring)	Programmable output of 0V or 24V when an adjustable limit is undercut/exceeded.
	7. Empty Pipe	Programmable output of 0V or 24V when the measuring pipe is empty or too many bubbles/particles detected.
3	GND	Versorgungsmasse: 0 V
4	Digital input I1	
	1. Dosing	Starts the dosing process at 24V edge.
	2. Set Offset	Starts offset adjustment, at 24V edge.
	3. Reset Counter	Reset the counter on 24V edge
5	Analog Output QA	4 ... 20mA; 0 ... 20mA
		For example: 0l/min → 4mA 36l/min → 20mA (depending on the nominal diameter) Empty pipe alarm → 3,5mA
6	Communication	RS485A
7	Communication	RS485B
8	Shield	EMC safety

**Cable 8-wire with 1-wire communication**

Wire configuration defined by manufacturer.

The inputs and outputs can be reprogrammed for specific applications.

Colour	Function	Description
Red	24 VDC	Power Supply: 18 ... 30 VDC
Brown	Digital Output Q1	Freely adjustable in the range from 0.1 to 3000 ml/pulse (or ml/s/Hz), in steps of 0.1. NPN or PNP transistor. Maximum load 100mA*. Max. Voltage must be less than supply voltage.
	1. Pulse Output	Output in ml/pulse, depending on the pulse value setting.
	2. Increased tolerance for particle or gas inclusions (TPG)	Programmable output of 0V or 24V on detection of solid particles or air bubbles and change to "TPG" software mode.
	3. Frequency output	Output in Hz, depending on the pulse value setting.
	4. Dosing	Programmable output of 0V or 24V while dosing is running.
	5. Negative Flow	Programmable output of 0V or 24V in case of negative flow.
	6. Lower or upper limit (limit value monitoring)	Programmable output of 0V or 24V when an adjustable limit is undercut/exceeded.
	7. Empty Pipe	Programmable output of 0V or 24V when the measuring pipe is empty or too many bubbles/particles detected.
Black	GND	Power supply ground: 0 V
Green	Digital Output Q1	Freely adjustable in the range from 0.1 to 3000 ml/pulse (or ml/s/Hz), in steps of 0.1. NPN or PNP transistor. Maximum load 100mA*. Max. Voltage must be less than supply voltage.
	1. Pulse Output	Output in ml/pulse, depending on the pulse value setting.
	2. Increased tolerance for particle or gas inclusions (TPG)	Programmable output of 0V or 24V on detection of solid particles or air bubbles and change to "TPG" software mode.
	3. Frequency output	Output in Hz, depending on the pulse value setting.
	4. Dosing	Programmable output of 0V or 24V while dosing is running.
	5. Negative Flow	Programmable output of 0V or 24V in case of negative flow.
	6. Lower or upper limit (limit value monitoring)	Programmable output of 0V or 24V when an adjustable limit is undercut/exceeded.
	7. Empty Pipe	Programmable output of 0V or 24V when the measuring pipe is empty or too many bubbles/particles detected.
Violet	Analog Output QA	4 ... 20mA; 0 ... 20mA
		For example: 0l/min → 4mA 36l/min → 20mA (depending on the nominal diameter) Empty pipe alarm → 3,5mA
Yellow	Communication	Communication interface
Orange	Digital input I1	
	1. Dosing	Starts the dosing process at 24V edge.
	2. Set Offset	Starts offset adjustment, at 24V edge.
	3. Reset Counter	Reset the counter on 24V edge
	4. Creeping Flow Off	Deactivates the creeping flow suppression while 24V is active.
Blue	Shield	EMC safety

\* Q1 + Q2 ≤ 100mA

**Cable 8-wire with 2-wire communication**

Wire configuration defined by manufacturer.

The inputs and outputs can be reprogrammed for specific applications.

Colour	Function	Description
Red	24 VDC	Power Supply: 18 ... 30 VDC
Brown	Digital Output Q1	Freely adjustable in the range from 0.1 to 3000 ml/pulse (or ml/s/Hz), in steps of 0.1. NPN or PNP transistor. Maximum load 100mA*. Max. Voltage must be less than supply voltage.
	1. Pulse Output	Output in ml/pulse, depending on the pulse value setting.
	2. Increased tolerance for particle or gas inclusions (TPG)	Programmable output of 0V or 24V on detection of solid particles or air bubbles and change to "TPG" software mode.
	3. Frequency output	Output in Hz, depending on the pulse value setting.
	4. Dosing	Programmable output of 0V or 24V while dosing is running.
	5. Negative Flow	Programmable output of 0V or 24V in case of negative flow.
	6. Lower or upper limit (limit value monitoring)	Programmable output of 0V or 24V when an adjustable limit is undercut/exceeded.
	7. Empty Pipe	Programmable output of 0V or 24V when the measuring pipe is empty or too many bubbles/particles detected.
Black	GND	Power supply ground: 0 V
Orange	Digital input I1	
	1. Dosing	Starts the dosing process at 24V edge.
	2. Set Offset	Starts offset adjustment, at 24V edge.
	3. Reset Counter	Reset the counter on 24V edge
Violet	Analog Output QA	4 ... 20mA; 0 ... 20mA
		For example: 0l/min → 4mA 36l/min → 20mA (depending on the nominal diameter) Empty pipe alarm → 3,5mA
Yellow	Communication	RS485A
Green	Communication	RS485B
Blue	Shield	EMC safety

**ATTENTION:**

The Flowmax 42i measuring device may only be operated within the limits specified on the nameplate and in the operating manual/data sheet. Unauthorized operating conditions can lead to overloads, damage or defects.



**IMPORTANT!**

### 3. Commissioning

#### NOTE:

After starting up the electronics, the device is ready for use, but it reaches its optimum operating state after 30 minutes. It makes sense to carry out a basic trim or set offset adjustment only after this warm-up phase.

**NOTICE!**

#### NOTE:

If Flowmax 42i is used for a fluid other than water the "basic trim" has to be carried out during commissioning. Therefore, the device has absolutely be filled with medium.

**NOTICE!**

The basic trim can be done on the device display (alternatively FlowCon 200i). During the adjustment, the medium may not flow, as this can lead to a measurement deviation. If there is a possible flow, it will be stored as "zero point".

#### 3.1 Operation

If Flowmax 42i is used as a flowmeter for water or water-like liquids, it generally requires no on-site operation, as the parameters listed below have a factory setting that ensures optimal function. However, Flowmax 42i can also be supplied with customer-specific settings.

**NOTE:** If necessary, e.g. if viscosity and/or speed of sound deviate significantly from water, the pre-set parameters can be adjusted via the display or FlowCon 200i.

**NOTICE!**

The following parameters may be changed to settings suitable for the individual conditions: for 5-pin version

- Digital output Q1, function and behavior
- Analog output QA, function and behavior
- Flow range, for which shall apply 4 ... 20mA resp. 0 ... 20mA
- Pulse value
- Creeping suppression
- RS485 Communication (option)
- Optimization of measurement curve with up to 8 interpolation values (Medium matrix requires FlowSoft\*)

The following parameters may be changed to settings suitable for the individual conditions: for 8-pin version

- Digital output Q1, function and behavior
- Digital output Q2, function and behavior
- Digital input I1, function and behavior
- Analog output QA, function and behavior
- Flow range, for which shall apply 4 ... 20mA resp. 0 ... 20mA
- Pulse value
- Creeping suppression
- RS485 Communication (option)
- Optimization of measurement curve with up to 8 interpolation values (Medium matrix requires FlowSoft\*)

\*FlowSoft is the MIB programming software (option)

### 3.1.1 Display and user menu

Flowmax 42i is equipped with a display to visualize actual measurement values and to change parameters of the flowmeter. Menu navigation and parameter changes are controlled by the four keys on the foil keypad.




Figure 11: Operating with the key pad

Press the “Set” key to display the main menu. Different menu options can be selected by using the two arrow keys. To confirm a menu item, press the “Set” button again.

To enter e.g. analog limits “Analog output – Upper limit” use the arrow keys to change values and press “Set” to confirm. To switch back to the last menu level press the “Esc” key. As soon as the operator tries to change values the user will be prompted to enter a password. Password protection is used to ensure changes to values or configurations are done by authorized personnel. The default password for Flowmax 42i is **41414**. The user level will remain active for 30 minutes after the last press on any button. 200 seconds after the last key press, the device skips the menu and returns to the display mode, which does not apply to the menu items diagnostic and dosing. Here, the unit remains in the submenu until the operator exits the submenu again with the ESC key.

Operating examples see appendix.

**NOTE:**

The display always shows the currently set activated parameter of the menu first. The activated parameter is displayed inverted.

**NOTICE!**

**NOTE:**


In the menu all the possible functions of the device are visible.

**NOTICE!**

The functions of Digital Output Q2 and Digital Input I1 are only available on the Flowmax version with 8-pin plug.

The “PID controller” and “speed of sound” functions displayed under the Analog output - Output value menu item are only provided with functionality if they were selected when ordering (option).

Flowmax 42i without display has the same features as the display version, but you can change parameters only with the FlowCon 200i display and programming unit. (option)






Figure 12: Menu structure Flowmax 42i

## 3.2 Functionalities of flowmeter and default settings

### 3.2.1 Language

The language of the display can be changed. Available languages are English, Spanish, French and German.

### 3.2.2 Dosing

The Flowmax 42i can be configured for manually dosing by choosing the dosing function via the user display. The Volume “Dosing Quantity” and the “Dosing Time” are freely adjustable. The dosing time is intended as a safeguard against unintentional overspill. After the set time has passed, the output switches regardless of the measured quantity. When “Dosing Time” is set to zero, the timer control is inactive. A dosage can be started and stopped with the menu function keys “Start” and “Stop”.

Setting range “Dosing Quantity”: 0 ... 3500 liters, in steps of 0.001 liters  
 Default setting “Dosing Quantity”: 0 liters

Setting range “Dosing Time” 0 ... 30000 Seconds, in steps of 1 sec,  
 having an accuracy of +0/-1 sec

Default setting “Dosing Time”: 3 Seconds

Example:

Dosing time = 3 seconds. That means Flowmax is sending the closing signal after 2.1 to 3.0 sec to the valve. The dosing time is intended as a safety function and should be selected insignificantly longer than the actual time required for dosing. This ensures that possible malfunctions/leakages in the structure/system are detected at an early stage. An exact dosage purely on the dosing time is not useful.

#### **IMPORTANT!**

If Dosing Time = 0 the time switch-off is inactive.

To be able to activate dosing, a digital output must be parameterized for dosing. Dosing can be started both via the menu and via the digital input.

#### **WARNING!**

**The customer has to provide a technical solution for overflow protection and an emergency stop switch. Both functions must lead to valve shutoff for safety reasons.**



**IMPORTANT!**



**WARNING!**

### 3.2.3 Media

#### 3.2.3.1 Set Offset

In the sub menu “Set Offset” it is possible to set the actual offset of the flowmeter. Use this function only when Flowmax 42i is completely filled with liquid, and there is no flow, as this condition is the new “zero” value.

Example of operation see appendix.

Flowmax 42i automatically does a small offset change, e.g. caused by variable temperatures. It is also possible to set the offset via the configurable digital input I1.

#### IMPORTANT!

In contrast to the basic trim, the Set Offset is not stored in the device. When the Flowmax 42i is restarted, the original, last stored value is active.



**IMPORTANT!**

#### 3.2.3.2 1-Pt-Correction

Setting range: -50.0 ... 50.0 % in steps of 0.1%

Default setting: 0 %

Example of operation see appendix.

#### 3.2.3.3 Creeping suppression

Creeping flow suppression is used to exclude flows from the measurement that can occur within a narrow range around zero, even when the valve is closed, due to convection. The factory setting of the creeping flow suppression is set to a sensible standard value in relation to the cross-section of the measuring device.

There are higher tolerances below the standard default settings, see also section 5.3 → “measurement deviation”!

Creeping suppression works with a hysteresis of 0% to - 25%.




Figure 13: Function of creeping suppression illustrated with 0.6 l/min

Example: Creeping suppression = 0.6 l/min  
 If the flow rate falls below a value of 0.45 l/min, creeping flow suppression is activated. If the flow rate exceeds 0.6 l/min, the flow rate is again output as a pulse and added to the daily quantity counter. A value is also displayed to the analog output again.

Setting range: 0.0 ... 19.2 l/min, in 0.0006 l/min steps  
 Default settings: DN 3: 0.012 l/min  
 DN 5: 0.024 l/min  
 DN 7: 0.09 l/min  
 DN10: 0.3 l/min  
 DN15: 0.9 l/min

**Lag Creeping Flow**

The activation of the creeping suppression can be delayed. The value is adjustable via menu.




Figure 14: Function Lag Creeping Flow

Setting range: 0 ... 99.0 s in steps of 0.1 s  
 Default settings: 0.5s

**3.2.3.4 Basic Trim**

The “Basic trim” function enables optimum adjustments to the medium-specific characteristics. By executing this function, Flowmax 42i runs through an internal parameterization and saves relevant parameters automatically. This process can take up to approx. 1 minute.

**IMPORTANT!**

To ensure that the calibration can be carried out correctly, the device must be filled with liquid and there must be no flow.  
 If an error is detected during adjustment, e.g. because the device is not filled, “Error” appears on the display. If the calibration was performed successfully, the message “Completed” is displayed.



### 3.2.4 General Settings

#### 3.2.4.1 Reset Counter

The volume counter of Flowmax 42i can be reset.  
Example of operation see appendix.

#### **IMPORTANT!**

Accidentally deleted counter readings can't be restored. After the reset, the count starts again at the value 0.



**IMPORTANT!**

#### 3.2.4.2 TPG (tolerance against solid particles and gas inclusions) (option)

Ultrasonic flow measurement is a volume measurement. A precise measurement can only be guaranteed if the pipe is completely filled and the liquid is not outgassed or doesn't contain any solid particles. Gas bubbles and solid particles lead to measurement errors and can result in an alarm message if they occur more frequently. The TPG function can tolerate a significantly higher amount of gas bubbles or solid particles and therefore enables the flow measurement to be maintained for a longer period of time.

If the maximum possible amount of air bubbles or particles is exceeded, the Flowmax switches to the empty pipe alarm.

When the option is activated, the Flowmax automatically switches to "TPG" mode if the reception amplitude is insufficient. The active status is shown in the top line of the display and emitted at the digital output, provided this has been parameterized with the function.

Setting range: Off, On

Default settings: Off

#### 3.2.4.3 Empty pipe delay

Small air bubbles or particles, which are carried with the liquid, disturb the sound transmission in the measuring pipe.

The last undisturbed flow value is output during the set time, but for a maximum of 3 seconds. After that, the behavior is similar to a non-existent flow rate. The measuring device only switches to alarm status after the configured delay time.

Setting range: 0.0 ... 3000.0 s

Default settings: 0.5 s for all DN

### 3.2.4.4 Hysteresis

The limit values can be provided with a hysteresis. This is to prevent frequent switching of the outputs when the flow moves around a limit value.




Figure 15: Function Hysteresis at limit

Setting range: 0 ... 8000.00 ml/s in steps of 0.01 ml/s.  
 Default settings: 0 for all DN

### 3.2.4.5 Lower Limit

Here, the lower limit for the digital output is set.

Setting range: 0 ... 20000 ml/s in steps of 0.01 ml/s.  
 Default settings: 0 for all DN

### 3.2.4.6 Upper Limit

Here, the lower limit for the digital output is set.

Setting range: 0 ... 20000 ml/s in steps of 0.01 ml/s.  
 Default settings: max. Flow of the flowmeter (depending on the diameter)

DN3:	25 ml/s
DN5:	50 ml/s
DN7:	100 ml/s
DN10:	400 ml/s
DN15:	1000 ml/s

### 3.2.4.7 Pulse value

Here you can specify the flow rate, sonic speed (Speedmax option), or temperature at which an output pulse is displayed.

Choose a configuration which will neither exceed the maximum output frequency of the Flowmax 42i (10kHz) nor the maximum input frequency of the plc. The pulse/pause ratio is 1:1. The pulse length is limited to 1s.

Example: 2.0 ml/pulse

This means: a pulse is emitted every 2.0 ml.  
 Setting range: 0.1 ... 3000.0 ml/pulse, in steps of 0.1 ml/pulse  
 Default setting: 1.0 ml/pulse for DN5, 7, 10, 15  
 0.1 ml/pulse for DN3

Flow ml/s	Pulse value ml/pulse	Frequency Hz	Period s	Duration of the pulse	
				s	ms
1	1	1	1	0.5	500
100	1	100	0.01	0.005	5
1000	0.1	10000	0.0001	0.00005	0.05
100	10	10	0.1	0.05	50
0.5	10	0.05	20	1	1000

In the last case every 20 seconds, a pulse of 1 second duration is put out.

### 3.2.4.8 Total Counter

The Total Counter can be displayed in the menu. The unit is fixed to m<sup>3</sup>. This counter is unidirectional and can therefore differ from the daily counters. The Total Counter can not be set to zero!

**NOTICE!**

### 3.2.4.9 Counter

The counter that appears on the standard screen is the daily quantity counter. The unit corresponds to the currently set one. The behavior of the daily quantity counter:

a) at daily amount in [l]

from [l]	to [l]	resolution display [l]
0.000	14000	0.001
14000	28000	0.002
28000	56000	0.004
56000	112000	0.008
112000	225000	0.016
225000	445000	0.032
445000	1000000	0.064

Once the counter has reached 1000000 liters, it automatically begins to count up from zero. The total counter continues to run without being reset.

b) at daily amount in [m<sup>3</sup>]

from [m <sup>3</sup> ]	to [m <sup>3</sup> ]	resolution display [m <sup>3</sup> ]	rounding error -0.05%
0.000	14000	0.001	
14000	28000	0.002	
28000	56000	0.004	
56000	112000	0.008	
112000	225000	0.016	
225000	461204	0.032	

Once the counter has reached 461204 m<sup>3</sup>, it automatically begins to count up from zero. Total counter runs without resetting on.

c) at daily amount in [US-Gal]

from [Gal]	to [Gal]	resolution display [Gal]	rounding error +0.12%
0.000	14000	0.001	
14000	28000	0.002	
28000	58000	0.004	
58000	112000	0.008	
112000	225000	0.016	
225000	460000	0.032	
445000	1000000	0.064	

Once the counter has reached 1000000 Gal it automatically begins to count up from zero. Total counter runs without resetting on.

### 3.2.5 Display

#### 3.2.5.1 Units

Flowmax 42i is able to show actual flow or the volume in different units.

Setting range: ml/s + l, l/h + l, l/min + m<sup>3</sup>, Gal/min +Gal, l/min + l

Default setting: ml/s + l

Example: ml/s + l

Here, the flow appears in the unit "ml / s" (milliliters per second) and the daily amount in "l" (liters).

Gal are US Gal with 1 Gal = 3,785 l.

#### 3.2.5.2 Filter for Display

The indicated flow can additionally be filtered. This filter is an average over the last 16s. It can be activated and deactivated via the menu.

Setting range: Off, On

Default setting: Off

#### 3.2.5.3 Rotate Display

The display can be rotated in steps of 90°.

Setting range: 0°, 270°, 180°, 90°

Default setting: 0°

### 3.2.5.4 Flashing

The display flashes in case of an error. This can be switched off.

When activating the alarm flashing, the backlight first flashes after 150s. The time is extended by the set empty pipe delay time, when the empty pipe delay is active.

Setting range: On, Off

Default setting: On

The alarm flashing can be muted for 150 seconds by pressing the ESC key.

### 3.2.6 Analog Output QA

#### 3.2.6.1 Function

The Analog Output is an active current output with 0 ... 20mA or 4 ... 20mA. It can be adjusted via the display menu or FlowCon 200i.




Figure 16: The analog output is active

Setting range: 0 ... 20mA, 4 ... 20mA, off

Default setting: 4 ... 20mA

The analog output ranges from 0 to 22.6mA measuring the flow rate or the condition of the flow measurement.


The values here signify for 4 ... 20mA configuration:

- 20 mA the max range of the relevant measurement
- 4 mA the min range of the relevant measurement
- 3.5 mA empty pipe

Max range and min range parameters can be set within the type-specific measurement of the device. The value of the max range must be greater than the value of the min range, so that the values are stored. By default, the min range is 0 mA or 4 mA and the respective end of the measuring range is set to 20 mA.

#### IMPORTANT!

If the analog output is used, the maximum resistance  $R_i$  should not be more than 500 Ohm, otherwise it can't be guaranteed that the measuring device can deliver the maximum value.




**IMPORTANT!**

**Characteristic curves analog output**

- **0 ... 20mA**

For the following graphic “min Range” is used for 0% and “max Range” is used for 100%.




Value	Current [mA]
Smaller 0%	0
0% (min Range)	0
Between 0% and 100%	Linear interpolation from 0 ... 20 mA
100% (max Range)	20
Bigger 100%	20

Figure 17: Characteristic curve 0 ... 20mA

- **4 ... 20mA**

For the following graphic “min Range” is used for 0% and “max Range” is used for 100%.



Value	Current [mA]
Empty pipe	3.5
Smaller -1.2%	3.8
Between -1.2% and 0%	Linear interpolation from 3.8 ... 4mA
0% (min Range)	4
Between 0% and 100%	Linear interpolation from 4 ... 20mA
100% (max Range)	20
Between 100% and 103%	Linear interpolation from 20 ... 20.5mA
Bigger 103%	22.6


Figure 18: Characteristic curve 4 ... 20mA

### 3.2.6.2 Filter

The function "Filter" averages the analog output signal. Possible settings:

Setting range: Weak, Medium, Strong, off  
 Default setting: Weak

With weak averaging, the analog output signal reacts more quickly. With strong averaging, the response of the analog value is slowly.



Filter	100%
off	16ms
weak	0,3s
medium	3s
strong	30s

Figure 19: Function Filter of analog output

### 3.2.6.3 Output Value

In the menu all output values are visible. The optional features are only available when they are ordered. If a not ordered function is selected, the output will be set on "Flow".

**NOTICE!**

Setting range: Flow, PID-Controller, Speed of Sound, Temperature  
 Default setting: Flow

#### Flow measurement for the analog output

Via the analog output of the measured flow is output.

#### PID Controller for the analog output (Option)

It is possible to implement flow control on the current output. FlowSoft\* is required to set the parameters (target flow, proportional factor, integral factor and differential factor).

If this function is selected via the menu (see point 3.1.1 Fig. 11. Menu structure Flowmax 42i in the section Analog Output QA - Output Value) and the function PID Controller has not been ordered, the output is set to "Flow".

\*FlowSoft is the MIB programming software (option)

#### Speed of Sound for the analog output (Option)

If this function is selected via the menu (see Section 3.1.1 Fig 12. Menu structure Flowmax 42i in the section Analog Output QA - Output Value) and the function Speed of sound has not been ordered, the output is set to "Flow".

**Temperature measurement for the analog output**

The measured temperature is displayed via the analog output.

The temperature sensor is not in contact with the medium. It is used to calculate the expansion of the measuring channel in the case of temperature fluctuations. The sensor is influenced by the ambient temperature. The temperature value reacts slowly because it measures the plastic temperature inside the sensor pocket.




Figure 20: Deviation of temperature measurement

**Min Range**

The value at which 0 or 4 mA is to be displayed is set here in the selected unit.

Setting range: 0.00 to 19999.99 in steps of 0.01

Default setting: 0 ml/s

**Max Range**

The value at which 20 mA is to be displayed is set here in the selected unit.

Setting range: 0.01 to 20000.00 in steps of 0.01

Default setting: max Flow of the flowmeter (depending on diameter)

- DN 3: 25
- DN 5: 50
- DN 7: 100
- DN 10: 400
- DN 15: 1000

**NOTE!**

The value "Min Range" cannot be set bigger than or equal to the "Max Range".

**NOTICE!**

### 3.2.7 Digital Outputs Q1 and Q2 (Q2 only available with 8-pin plug)

The digital outputs Q1 and Q2 can be used as pulse output, to display the “TPG” status, to signal the empty pipe message, to control a dosing valve or for limit value monitoring.

If “Pulse output” is selected on one of the two digital outputs, the “Frequency output” setting can't be selected on the other digital output.

In the case of a short circuit or overload, the digital outputs are set to high resistance for 2 s after approx. 100 µs. The output is then retried.

Setting range: Off, Pulse Output, TPG, Frequency output, Dosing, Negative Flow, Lower Limit, Upper Limit, Empty Pipe

Default setting Q1: Pulse Output

Default setting Q2: Empty Pipe

Depending on the application, NPN or PNP logic can be selected.

Setting range: PNP / NPN, normal closed / normal open

Default setting Q1: PNP normal open

Default setting Q2: PNP normal open

#### Pulse output / Frequency output

	Empty pipe	Filled, no flow	Filled, flow
0V normal closed	0V	0V	High resistance
0V normal open	0V	0V	High resistance
24V normal closed	High resistance	High resistance	24V Pulses
24V normal open	High resistance	High resistance	24V Pulses

#### TPG output

	Empty pipe	Air/particles in the measuring pipe in TPG mode	Filled pipe
0V normal closed	0V	High resistance	0V
0V normal open	High resistance	0V	High resistance
24V normal closed	24V	High resistance	24V
24V normal open	High resistance	24V	High resistance

#### Empty pipe output

	Empty pipe	Air/particles in the measuring pipe in TPG mode	Filled pipe
0V normal closed	High resistance	0V	0V
0V normal open	0V	High resistance	High resistance
24V normal closed	High resistance	24V	24V
24V normal open	24V	High resistance	High resistance

#### Dosing output

	Startup of device	While dosing	Before/after dosing
0V normal closed	High resistance	High resistance	0V
0V normal open	High resistance	0V	High resistance
24V normal closed	High resistance	High resistance	24V Pulses
24V normal open	High resistance	24V Pulses	High resistance

Lower limit output

	Below lower limit	Between the limits	Above upper limit
0V normal closed	0V	High resistance	High resistance
0V normal open	High resistance	0V	0V
24V normal closed	24V	High resistance	High resistance
24V normal open	High resistance	24V	24V

Upper limit output

	Below lower limit	Between the limits	Above upper limit
0V normal closed	High resistance	High resistance	0V
0V normal open	0V	0V	High resistance
24V normal closed	High resistance	High resistance	24V
24V normal open	24V	24V	High resistance

**IMPORTANT!**

With an inductive load, e.g. relays, an additional freewheeling diode must be installed antiparallel to the load.



**IMPORTANT!**

Example 1: Flowmax 42i via NPN (0V), external relay




Figure 21: Connecting Digital Output to relay

Example 2: Flowmax 42i via PNP (24V), external counter e.g. PLC




Figure 22: Connecting Digital Output to counter

With high impedance input counters and highspeed counting, it may be necessary to include a resistor to have clean edges.

### 3.2.8 Digital Input I1 (only available with 8-pin plug)

Flowmax 42i has a digital input to which the functions can be assigned. For example, to start a dosing process, the line must be connected to 24V. The dosing parameters can be stored in the device either via the device display or FlowCon 200i.

Setting range: Off, Dosing, Set Offset, Reset Counter, Creeping Flow Off  
 Default setting: Off

The dosing input is locked so that a re-start is not possible during a running dosing process.

Available input functions:

	Dosing	Set Offset	Reset Counter	Creeping Flow Off	aus
0V	-	-	-	-	-
24V	Rising edge: 0 → 24V Start dosing	Rising edge: 0 → 24V Set Offset	Rising edge: 0 → 24V Counter is reset	State: Deactivating creeping flow	-
Only perform when the medium is standing still					

#### IMPORTANT!

The "Set Offset" input function may only be carried out when the medium is at a standstill. If a Set Offset is carried out when the flow is active, incorrect measurements may occur until the adjustment has been carried out correctly.



**IMPORTANT!**

### 3.2.9 Diagnostic

Current device parameters such as software versions etc. can be viewed under the "Diagnostics" menu item. This information is required for servicing.

#### NOTE!

Before contacting MIB, please note the values "Fab. no.", "Versions", "Values".

**NOTICE!**

#### 3.2.9.1 Testing Flow

A test flow can be set for checking the process system. In this case, the measuring device behaves as if the test flow is actually flowing, even if the measuring device is empty. To start the simulation, "Start" must be selected "Stop" ends the simulation.

When the device is restarted, the test flow is stopped and the value is deleted.

Setting range: 0 ... 3200.0 ml/s in steps of 0.1 ml/s

### 3.3 Overview of default settings


Function	Default settings
Pulse value	1 ml/pulse (0.1 ml/pulse for DN3)
Digital output Q1	Pulse output as PNP (24V) normal open
Digital output Q2 *	Empty pipe output as PNP (24V) normal open
Digital input I1 *	No function assigned
Analog output QA	Flow as 4 ... 20mA signal 20mA → 1,5 l/min at DN 3 3 l/min at DN 5 6 l/min at DN 7 24 l/min at DN10 60 l/min at DN15
Creeping suppression	0.012 l/min at DN 3 0.024 l/min at DN 5 0.09 l/min at DN 7 0.3 l/min at DN10 0.9 l/min at DN15

\* Option

### 3.4 General Information

Please check the following before powering the flowmeter for the first time:

- Check the electrical connections and cable allocations.
- Check the installation position of the flowmeter. Is the direction of the arrow on the housing/name plate and the actual flow direction in the pipe congruent?



**IMPORTANT!**

Once these checks have been carried out and the corresponding conditions have been checked, switch on the power supply. The device will reach optimum operating status after 30 minutes. See 3. Commissioning.

Flowmax 42i is operational!

## 4. Exchange of flowmeter

- **Switch off power before disconnecting the electrical connections!**
- **When removing the device, observe the safety instructions in chapter 2.3 Electrical wiring.**
- Please note that after replacing the flowmeter
  - a) Specific programming of the previous flowmeter should be noted and programmed to the new flowmeter
  - b) when using the dosing function, set a quantity



**WARNING!**

If the device requires a configuration change, the display and programming unit FlowCon 200i may be required (see section 6. Accessories).

### Repair, hazardous substances

Before sending the flowmeter Flowmax 42i for repair, the following precautions must be taken:

- **Clean all process chemicals from the device. Fully rinse the flow path. Please pay close attention to the process fittings. All media must be removed before returning. This is particularly important, if the medium to be measured is health hazardous.**



**WARNING!**

**Measuring devices that are not or insufficiently cleaned will be returned to the sender for cleaning without testing!**

- **Always enclose a declaration of decontamination with the measuring device with as precise a description of the fault as possible, the application in which the measuring device was used and the chemical-physical properties of the measured medium.**




**WARNING!**

Costs resulting from insufficient cleaning of the measuring device for possible disposal or personal injury (chemical burns, etc.) will be charged to the sender of the measuring device.

To ensure that your repair order is processed quickly and efficiently, it is important that you provide us with a contact person with a phone number and e-mail address who can answer any technical questions our service staff may have.


## 5. Technical specifications

### 5.1 Dimensions and weight of the compact version




Nominal diameter	Height A [mm] [in]	Depth B [mm] [in]	C [mm] [in]	D	Width E [mm] [in]	F [mm] [in]	G [mm] [in]	Weight [g] [lbs]
DN3	167.5 6.59	50 1.97	23 0.91	G1/2	25 0.98	7 0.28	98 3.86	670 1.48
DN5	167.5 6.59	50 1.97	23 0.91	G1/2	25 0.98	7 0.28	98 3.86	670 1.48
DN7	167.5 6.59	50 1.97	23 0.91	G1/2	25 0.98	7 0.28	98 3.86	670 1.48
DN10	170.5 6.71	50 1.97	23 0.91	G3/4	26.5 1.04	10 0.39	95 3.74	720 1.59
DN15	175.5 6.91	55 2.17	25 0.98	G1	29 1.14	15 0.59	90 3.54	895 1.97

### 5.2 Dimensions and weight of the separated version



Weight: 330g [0.73 lbs]



Nominal diameter	A [mm] [in]	B [mm] [in]	C [mm] [in]	D [mm] [in]	E [mm] [in]	F [mm] [in]	G	Weight [g] [lbs]
DN3	148 5.83	82.5 3.25	70 2.76	121 4.76	50 1.97	27 1.06	G1/2	390 0.86
DN5	148 5.83	82.5 3.25	70 2.76	121 4.76	50 1.97	27 1.06	G1/2	390 0.86
DN7	148 5.83	82.5 3.25	70 2.76	121 4.76	50 1.97	27 1.06	G1/2	390 0.86
DN10	152 5.98	92.5 3.64	80 3.15	122 4.80	45 1.77	31 1.22	G3/4	420 0.93

The cable between the measuring section and the transmitter may have a maximum length of 2 m (78.7 in). Standard is 0.5 m (19.6 in). The cable may subsequently not be changed in its length, because the instrument is tuned at the factory. It will be installed in the electronics (soldered) and is screwed to the measuring section on the plug.

### 5.3 Technical specifications

#### Housing

Nominal diameters	DN3, DN5, DN7, DN10, DN15
Connection inner thread	G1/2, G1/2, G1/2, G3/4, G1
Medium temperature	0 ... +50°C
Protection class	IP 65
Nominal pressure	PN10
Material	PE-HD (Polyethylene)

---

#### Electronics

Power supply	18 ... 30 VDC
Power input	at 24 VDC = 3.6 W
Connection	Plug 5 pins, option plug 8 pins
Ambient temperature	0 ... +50°C
Storage temperature	0 ... +50°C
Analog output QA	0/4 ... 20 mA, 0 ... 10 V (option) Min Range and max Range adjustable, Ground connected to supply ground Error Signal according to NAMUR NE43 at 4 ... 20 mA
Digital output Q1/2	via transistor NPN- and PNP -logic, max. 100 mA output voltage according to DIN 19240: ≤5 V means LOW ≥12 V means HIGH Short cut resistant Frequency 0 ... 10 kHz
Data interface	Communication interface RS485 (option); MODBUS (option)
Measuring deviation	± 2% of reading ± 0.15% full scale, optional ± 1% of reading ± 0.15% full scale Reference conditions (VDE/VDI 2642) Different in TPG mode
Measuring range	DN3: 0,012 ... 1,5 l/min DN5: 0,024 ... 3 l/min DN7: 0,09 ... 6 l/min DN10: 0,3 ... 24 l/min DN15: 0,9 ... 60 l/min
Repeatability:	0.5%

The measuring system Flowmax 42i meets the general EMC immunity requirements according to CE, EN 61000-6-3, EN 61000-4-2, EN 61000-4-3, EN 61000-4-4, EN 61000-4-5, EN 61000-4-6. It is in conformity with the requirements of the EC directives and has the CE label.

**Possible error text Flowmax 42i**

<b>Display text</b>	<b>Description</b>	<b>Behavior</b>
Empty Pipe	When "Empty Pipe" is detected, no flow measurement.	Display flashing + text
Low Voltage	When power supply is less than 16V the outputs are inactive.	Display flashing + text
Short Circuit	When over load of the digital outputs is detected (>100mA), outputs are inactive.	only text
Lower Limit	When the flow is less than an adjustable limit and the output is configured for limit control. At the same time the configured output is switched.	only text
Upper limit	When the flow is more than an adjustable limit and the output is configured for limit control. At the same time the configured output is switched.	only text
Sonic Speed	Actual sonic speed out of specified value. Can occur with media with the speed of sound outside the measurement window or with very small air bubbles.	only text
Overflow	Message appears if the measuring range is exceeded. This may also occur during start-up or when there are air bubbles. The message is 30 seconds visible even when the flow is within the allowable range. However, the measurement still works.	only text, message is displayed 30 sec

**6. Accessories****Flowmax connection socket**

Flowmax connection socket is used to power and connect Flowmax 42i to an external control unit.

Ordercode 507321 (Socket 5 pins)

Ordercode 507084 (Socket 8 pins)

**FlowCon 200i**

External display and programming unit for use in combination with ultrasonic flow measuring devices Flowmax. FlowCon 200i can also be installed as separate display for Flowmax.

Ordercode 908873 (FlowCon 200i for 5-pin Flowmax)

Ordercode 908891 (FlowCon 200i for 8-pin Flowmax)

**7. Shipment**

- Flowmax 42i

## Appendix

Examples of operation:

### Enter Password

Key	Display picture
<b>Set</b>	Password
4 x <b>^</b>	40000
<b>Set</b>	X0000
<b>^</b>	X1000
<b>Set</b>	XX000
4 x <b>^</b>	XX400
<b>Set</b>	XXX00
<b>^</b>	XXX10
<b>Set</b>	XXXX0
4 x <b>^</b>	XXXX4
<b>Set</b>	

### Reset Counter

<b>Set</b>	Dosing Media <b>General Settings</b> Display Analog Output QA
<b>Set</b>	<b>General Settings</b> Reset Counter
<b>Set</b>	<b>General Settings</b> <b>Reset Counter</b> Start?
<b>Set</b>	<b>General Settings</b> <b>Reset Counter</b> Done

**Set Offset**

Use this function only when Flowmax 42i is completely filled with liquid, and there is no flow. If the offset is set while flow is present or when the pipe is empty it will cause an offset drift what results in a faulty measurement.

<b>Set</b>	Dosing Media <b>General Settings</b> Display Analog Output QA
<b>∧</b>	Language Dosing <b>Media</b> General Settings Display
<b>Set</b>	<b>Media</b> Set Offset
<b>Set</b>	<b>Media</b> <b>Set Offset</b> Start?
<b>Set</b>	<b>Media</b> <b>Set Offset</b> Done

**1-point correction**

The 1-point correction is used to adjust the measuring device to one operating point.

For this purpose, a typical volume for the application is filled into a container and the weight is determined using a scale. Caution: Subtract the weight of the container.

Including the density of the medium results in the volume (volume = mass/density). This is compared with the display of the measuring device.

If, for example, the measuring device shows 2% more than determined with the scale, a value of -02.0% must be entered for the 1-point correction.

<b>Set</b>	Dosing Media <b>General Settings</b> Display Analog Output QA
<b>∧</b>	Language Dosing <b>Media</b> General Settings Display
<b>Set</b>	<b>Media</b> Set Offset
<b>V</b>	<b>Media</b> 1-Pt.-Correction
<b>Set</b>	<b>Media</b> <b>1-Pt.-Correction</b> -00.0%

Setting the sign  
Setting the value

Set Media  
1-Pt.-Correction  
Done

To enable the correction back to delivery, a correction of 00.0% is to be entered.

### **Display rotate 90°**

Set Dosing  
Media  
General Settings  
Display  
Analog Output QA

V Media  
General Settings  
Display  
Analog Output QA  
Digital Output Q1

Set Display  
Units

2 x V Display  
Rotate Display

Set Display  
Rotate Display  
0°

3 x V Display  
Rotate Display  
90°

Set Display  
Rotate Display  
90°  
Done

To return your display to its delivery setting, choose Rotate Display 0°.



**MIB GmbH**  
Messtechnik und Industrieberatung  
Bahnhofstr. 35  
D-79206 Breisach  
Tel. 0049 / (0)7667 / 20 777 90  
Fax 0049 / (0)7667 / 20 777 99  
E-Mail: [info@mib-gmbh.com](mailto:info@mib-gmbh.com)  
Internet: [www.flowmax.de](http://www.flowmax.de)